



Features

- Synchronizes up to four separate high-speed Cobalt or Onyx I/O modules
- Synchronizes sampling and data acquisition for multichannel systems
- Synchronizes gating and triggering functions
- Clock rates up to 1.8 GHz
- Front panel MMCX connectors for input signals
- Front panel µSync connectors compatible with a range of Pentek Cobalt and Onyx modules

General Information

The Model 5692 High-Speed Synchronizer and Distribution board synchronizes multiple Pentek Cobalt or Onyx modules within a system. It enables synchronous sampling and timing for a wide range of multichannel high-speed data acquisition, DSP, and software radio applications.

Up to four modules can be synchronized using the 5692, with each receiving a common clock along with timing signals that can be used for synchronizing, triggering and gating functions.

Input Signals

Model 5692 provides three front panel MMCX connectors to accept input signals from external sources: one for clock, one for gate or trigger and one for a synchronization signal. Clock signals can be applied from an external source such as a high performance sine-wave generator. Gate/trigger and sync signals can come from an external system source. In addition to the MMCX connector, a reference clock can be accepted through the first front panel µSync output connector, allowing a single Cobalt or Onyx board to generate the clock for all subsequent boards in the system.

Output Signals

The 5692 provides four front panel µSync output connectors, compatible with a range of high-speed Pentek Cobalt and

Onyx modules. The μ Sync signals include a reference clock, gate/trigger and sync signals and are distributed through matched cables, simplifying system design.


Clock Signals

The 5692 can accept a user supplied external clock on its front panel MMCX connector. As an alternative to the external clock, the 5692 can use its on-board programmable voltage controlled crystal oscillator (VCXO) as the clock source. The VCXO can operate alone or be locked to a system reference clock signal delivered to the front panel reference clock input.

The external or on-board clock can operate at full rate or be divided and is used to register all sync and gate/trigger signals as well as providing a reference clock to all connected modules. In addition, the clock is available at the Clock Out MMCX as a sample or reference clock for other boards in the system.

Gate and Synchronization Signals

The 5692 features separate inputs for gate/trigger and sync signals. A programmable delay allows the user to make timing adjustments on the gate/trigger and sync signals before they are sent to buffers for output through the μ Sync output connectors.





 Pentek, Inc.
 One Park Way

 Upper Saddle River
 New Jersey 07458
 Tel: 201/818/5900
 Fax: 201/818/5904
 Email: info@pentek.com

 www.pentek.com

Calibration

The 5692 features a calibration output specifically designed to work with the 56640 or 56740 3.6 GHz A/D module and provide a signal reference for phase adjustment across multiple D/As.

Programming

The 5692 allows programming of operating parameters including: VCXO frequency, clock dividers, and delays that allow the user to make timing adjustments on the gate and sync signals. These adjustments are made before they are sent to buffers for output through the µSync connectors.

The 5692 is programmed via a TWSI control interface on the first μ Sync connector. The control interface is compatible with the front panel μ Sync connectors of all high-speed Cobalt and Onyx modules, thereby providing a single cable connection that carries both control and timing signals.

Supported Products

The 5692 supports all high-speed models in the Cobalt family including the 56630 1 GHz A/D and D/A AMC, the 56640 3.6 GHz A/D AMC and the 56670 Fourchannel 1.25 GHz, 16-bit D/A AMC. The 5692 will also support high-speed models in the Onyx family as they become available.

Specifications

Front Panel Sample Clock/Reference Input **Connector Type: MMCX** Input Impedance: 50 ohms Input Level: 0 dBm to +10 dBm, sine wave Sample Clock Frequency: 100 MHz to 2 GHz Reference Frequency: 5 to 100 MHz Front Panel Gate/Trigger & Sync Inputs Connector Type: MMCX Input Level: LVTTL Front Panel µSync Inputs/Outputs **Quantity:** 4 Connector Type: 19-pin µHDMI Signal Level: CML Signals (µSync connector 1): Reference Clock In, TWSI control In, Reference Clock Out, Gate/Trigger Out, Sync Out Signals (µSync connectors 2-4): Reference Clock Out, Gate/Trigger Out, Sync Out Front Panel Clock / Calibration Output Connector Type: MMCX Output Impedance: 50 ohms Output Level: +6 dBm nominal, sine wave Sample Clock Frequency: 100 MHz to 1.8 GHz **Programmable VCXO:** Frequency Ranges: 10-945 MHz, 970-1134 MHz, and 1213-1417.5 MHz Tuning Resolution: 32 bits Unlocked Accuracy: ±20 ppm PLL, Divider & Jitter Cleaner Type: Texas Instruments CDCM7005 Frequency Dividers: 1, 2, 3, 4, 6, 8 and 16 **PCI-Express Interface** PCI Express Bus: Gen. 1 x4 or x8, power only Environmental **Operating Temp:** 0° to 50° C Storage Temp: -20° to 90° C Relative Humidity: 0 to 95%, non-cond. Size: Single-width, full-height AMC module, 2.89 in. x 7.11 in.

Ordering Information

Model Description

5692 High-Speed Synchronizer and Distribution Board -AMC

Accessories

4 ea. 18" μSync cables are supplied; additional cables may be ordered: 2192-018 μSync cable - 18" 2192-036 μSync cable - 36"



 Pentek, Inc.
 One Park Way

 Upper Saddle River
 New Jersey 07458
 Tel: 201/818/5900
 Fax: 201/818/5904
 Email: info@pentek.com

 www.pentek.com